

ASSEMBLY INSTRUCTIONS

NOTE: ANTENNA SHOWN UPSIDE
DOWN FOR PURPOSE OF ILLUSTRATION.
TURN OVER WHEN MOUNTING ON MAST.

INSERT THIS HALF OF
BOOM INTO COUPLER
AND SECURE WITH
SCREW FURNISHED

